



**BARTELL
GLOBAL**

**PARTS
BOOK**

RIDE-ON TROWEL

BXR830, BXR830PRO



Doc. # PB-B19043
Orig. Rel. - 04/2021
Curr Rev. - 01



PAGE INTENTIONALLY LEFT BLANK



www.BartellGlobal.com

CANADA

170 Traders Blvd E
Mississauga, Ontario L4Z 1W7
TEL (647) 953-4100 FAX (647) 953-4101

KENTUCKY

4701 Allmond Ave
Louisville, Kentucky 40209
TEL (425) 405-9100 FAX (425) 405-9101

UK

Honeyholes Lane
Dunholme, Lincoln, UK LN2 3SU
TEL 01673 860709 FAX 01673 861119

NEW JERSEY

200 Commerce Drive, Unit A
Freehold, New Jersey 07728
TEL (848) 225-8100 FAX (848) 225-8101

**ORIGINAL LANGUAGE OPERATING MANUAL FOR
BARTELL RIDE-ON TROWELS**

© 2023 Bartell Global Inc.

No part of this work may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, or by any information storage or retrieval system without the prior written permission of Bartell Morrison Inc. unless such copying is permitted by federal copyright laws.

ADDRESS INQUIRIES OR REFERENCE PERMISSIONS CARE OF:

Bartell Global, 170 Traders Blvd E., Mississauga, Ontario, Canada, L4Z 1W7

REV.	DATE	DESCRIPTION	APPROVED BY:
0	04/2021	First Release	A. Nakkila
1	06/2023	Updated Parts List 1,4,5,6,7,9 and 13	A.Nakkila



TABLE OF CONTENTS

<u>PARTS LIST 1 – RIDE ON TROWELS</u>	5
BXR830, FRAME	5
BXR830, FRAME – PARTS LIST 1	6
<u>PARTS LIST 2 – RIDE ON TROWELS</u>	7
BXR830, GAS POWER PLANT	7
BXR830, GAS POWER PLANT – PARTS LIST 2	8
<u>PARTS LIST 3 – RIDE ON TROWELS</u>	9
BXR830, PROPANE POWER PLANT	9
BXR830, PROPANE POWER PLANT – PARTS LIST 3	10
<u>PARTS LIST 4 – RIDE ON TROWELS</u>	11
BXR830, DRIVING SYSTEM	11
BXR830, DRIVING SYSTEM – PARTS LIST 4	12
<u>PARTS LIST 5 – RIDE ON TROWELS</u>	13
BXR830, STEERING AND BLADE PITCH SYSTEM	13
BXR830, STEERING AND BLADE PITCH SYSTEM – PARTS LIST 5	14
<u>PARTS LIST 6 – RIDE ON TROWELS</u>	15
BXR830, GEARBOX ASSEMBLY, RIGHT (CCW)	15
BXR830, GEARBOX ASSEMBLY RIGHT (CCW) – PARTS LIST 6	16
<u>PARTS LIST 7 – RIDE ON TROWELS</u>	17
BXR830, GEARBOX ASSEMBLY, LEFT (CW)	17
BXR830, GEARBOX ASSEMBLY LEFT (CW) – PARTS LIST 7	18
<u>PARTS LIST 8 – RIDE ON TROWELS</u>	19
BXR830, SPRAY SYSTEM	19
BXR830, SPRAY SYSTEM – PARTS LIST 8	19
<u>PARTS LIST 9 – RIDE ON TROWELS</u>	20
BXR830, FOOT THROTTLE KIT	20
BXR830, FOOT THROTTLE KIT – PARTS LIST 9	20
<u>PARTS LIST 10 – RIDE ON TROWELS</u>	21
BXR830, FUEL TANK	21
BXR830, FUEL TANK – PARTS LIST 10	22
<u>PARTS LIST 11 – RIDE ON TROWELS</u>	23
BXR830, PROPANE TANK	23



BXR830, PROPANE TANK - PARTS LIST 11	24
<u>PARTS LIST 12 - RIDE ON TROWELS</u>	<u>25</u>
BXR830, STANDARD TRANSPORTER	25
BXR830, STANDARD TRANSPORTER - PARTS LIST 12	26
<u>PARTS LIST 13 - RIDE ON TROWELS</u>	<u>27</u>
BXR830, FRAME MOUNT TRANSPORTER	27
BXR830, FRAME MOUNT TRANSPORTER - PARTS LIST 13	28

PARTS LIST 1 – RIDE ON TROWELS

BXR830, FRAME




Figure 1: Frame



BXR830, FRAME – PARTS LIST 1

Part #	Description	QTY	Remarks
8360452	GUARD RING	1	
24210E	FOOT BOARD	1	
24211	COVER BOARD, THROTTLE	1	
24212	COVER BOARD, BOTTOM	1	
24213	COVER BOARD	1	
24214	COVER BOARD	1	
8360879	TOOLBOX	1	
8360453	SEAT	1	
24248	COVER CLUTCH	1	
8361073	WATER TANK, PLASTIC	1	
24253	WATER CAP	1	
8360464E	BATTERY BOX	1	
60005	BATTERY	1	
8360463E	BATTERY COVER	1	
8360968	CONNECTOR, BATTERY	1	
8360592	THROTTLE CONTROL	1	
24216	SAFETY SWITCH	1	
16045	LED LIGHT	2	
25131	POLISHING SKIRT	1	NOT SHOWN

PARTS LIST 2 – RIDE ON TROWELS

BXR830, GAS POWER PLANT




Figure 2: Gas Power Plant



BXR830, GAS POWER PLANT – PARTS LIST 2

Part #	Description	QTY	Remarks
21400	HONDA GX690	1	
8361423	ENGINE MOUNTING BAR	1	
8361423A	ENGINE MOUNTING BAR	1	
8361424	ENGINE MOUNTING BAR	1	
8361424A	ENGINE MOUNTING BAR	1	
24200	CLUTCH	1	
8360060	WASHER	1	
8360061	BUSHING	1	
8360064	WASHER	1	
8360529	BOLT	1	
9155	KEY	1	
8361607	OIL PIPE	1	
24217	WASHER	1	
8361611	BOLT	1	
8361610	BOLT	1	
8360314	PULLEY	1	
24218	MOUNTING PLATE, PULLEY	1	
24219	ADJUST PLATE, PULLEY	1	
24201	BELT	2	
24239	BELT TENSIONER ASSEMBLY	1	

PARTS LIST 3 – RIDE ON TROWELS

BXR830, PROPANE POWER PLANT




Figure 3: Propane Power Plant



BXR830, PROPANE POWER PLANT – PARTS LIST 3

Part #	Description	QTY	Remarks
21433	B&S, 627CC, PROPANE	1	
8361423	ENGINE MOUNTING BAR	1	
8361423A	ENGINE MOUNTING BAR	1	
8361424	ENGINE MOUNTING BAR	1	
8361424A	ENGINE MOUNTING BAR	1	
24252	CLUTCH	1	
21852	SPACER	1	
8360061	BUSHING	1	
8360064	WASHER	1	
8360529	BOLT	1	
9155	KEY	1	
8360314	PULLEY	1	
24218	MOUNTING PLATE, PULLEY	1	
24219	ADJUST PLATE, PULLEY	1	
24201	BELT	2	
24239	BELT TENSIONER ASSEMBLY	1	
21169	CATALYTIC MUFFLER	1	
16177	EMISSION DATA ANALYZER	1	NOT SHOWN
21854	REGULATOR MOUNT BRACKET	1	NOT SHOWN
24251	WIRING	1	NOT SHOWN
24250	KIT: HOSES, REGULATOR	1	NOT SHOWN

PARTS LIST 4 – RIDE ON TROWELS

BXR830, DRIVING SYSTEM




Figure 4: Driving System



BXR830, DRIVING SYSTEM – PARTS LIST 4

Part #	Description	QTY	Remarks
888361975	DRIVE LEVER, RIGHT	1	
888361976	DRIVE LEVER, LEFT	1	
888360501	T-CONNECTOR	2	
24220	BUSHING	4	
24221	BUSHING	4	
9030	LOCK PIN	2	
889502B	OIL CAP, STRAIGHT	2	NOT SHOWN
889502C	OIL CAP, 90 DEG	2	NOT SHOWN
24222	HANDLE GRIP	2	
24223	BUTTON, WATER SPRAY SYSTEM	1	
888360504	CONNECT SHAFT	1	
24224	CONNECT BEARING	6	
888360506	CONNECT SHAFT	2	
24225	U-CONNECTOR	6	
888360507	CONNECT SHAFT	2	
888360508	CONNECT SHAFT	2	
888360515	OSCILLATING SHAFT	1	
24226	BRACKET BEARING	1	
888360512	TUMBLE BOARD	1	
888360510	TRANSMISSION SHAFT	1	
888360511	TRANSMISSION SHAFT	1	
24227	BEARING	1	
24228	BEARING	1	
888360053	BEARING	1	
888369030	COTTER PIN	2	
888369259	NUT	6	
888369503	NUT	1	
888369504	LOCK WASHER	3	
888369506	PIN AND COTTER PIN	4	
888369507	BOLT	6	
888369508	THREADED ROD	6	
888369514	NUT	9	

PARTS LIST 5 – RIDE ON TROWELS

BXR830, STEERING AND BLADE PITCH SYSTEM




Figure 5: Steering and Blade Pitch System




BXR830, STEERING AND BLADE PITCH SYSTEM – PARTS LIST 5

Part #	Description	QTY	Remarks
24229	JOINT SHAFT	1	
24230	RUBBER COVER	2	
24202	GEARBOX, RIGHT	1	
24203	GEARBOX, LEFT	1	
888360491	BRACKET, RIGHT	1	
888360494	BRACKET	2	
888360485	BOLT	1	
888360492	BOLT	1	
888360484	BRACKET, LEFT	1	
21722	SLIDE BUSHING	2	
21725	SCREW	2	
21724	PIN	2	
24215	WIRE	2	
11802	LOCKNUT, M10	2	
9216	SCREW	2	

PARTS LIST 6 – RIDE ON TROWELS

BXR830, GEARBOX ASSEMBLY, RIGHT (CCW)






BXR830, GEARBOX ASSEMBLY RIGHT (CCW) – PARTS LIST 6

Part #	Description	QTY	Remarks
8364003R	GEARBOX CASING	1	
4464005	GEARBOX COVER	1	
8364010R	BRONZE GEAR	1	
8364013R	COUNTER SHAFT	1	
8354011R	MAIN SHAFT	1	
21842-1 21842-2	SHIMMING	A/R	
21734	PRESSURE WASHER	1	
21843-1 21843-2	SHIMMING	A/R	
21739	BEARING FLANGE	1	
21741	BEARING END CAP	1	
4364100	RELEASE VALVE	1	
9118	SCREW	8	
9145	SCREW	1	
10603	BEARING	1	
31369	BEARING	1	
21754	BEARING	1	
9043	SCREW	1	
9055	SEAL	1	
9064	GLASS EYE	1	
21747	PLUG	1	
9156	KEY	1	
24206	YOKE ARM	1	
21818	SHAFT, YOKE ARM	1	
9202	RETAINER RING	1	
21770	PRESSURE PLATE COVER	1	
8366003	PRESSURE PLATE	1	
24208	RIGHT SPIDER PLATE	1	
24233	LIFT LEVER	4	
24234	BUSHING	1	
24207	TROWEL ARM	4	
9059	NUT	8	
9066	SCREW	8	
9067	BOLT	4	
11903	BOLT	1	
21776	BEARING	1	
21757	SEAL	1	
50459	KEY	1	
31438	BEARING	1	
24258	BLADE, FINISH, 6"x10"	4	

PARTS LIST 7 – RIDE ON TROWELS

BXR830, GEARBOX ASSEMBLY, LEFT (CW)





BXR830, GEARBOX ASSEMBLY LEFT (CW) – PARTS LIST 7

Part #	Description	QTY	Remarks
8364003L	GEARBOX CASING	1	
4464005	GEARBOX COVER	1	
8364010L	BRONZE GEAR	1	
8364013L	COUNTER SHAFT	1	
8364011L	MAIN SHAFT	1	
21842-1 21842-2	SHIMMING	A/R	
21734	PRESSURE WASHER	1	
21843-1 21843-2	SHIMMING	A/R	
21739	BEARING FLANGE	1	
8364014	BEARING FLANGE	1	
4364100	RELEASE VALVE	1	
9118	SCREW	8	
10072	SCREW	1	
10603	BEARING	1	
31369	BEARING	1	
21754	BEARING	1	
9043	SCREW	1	
9055	SEAL	1	
9064	GLASS EYE	1	
21747	PLUG	1	
9156	KEY	1	
24206	YOKE ARM	1	
21818	SHAFT, YOKE ARM	1	
9202	RETAINER RING	1	
21770	PRESSURE PLATE COVER	1	
8366003	PRESSURE PLATE	1	
24209	LEFT SPIDER PLATE	1	
24232	LIFT LEVER	4	
24234	BUSHING	1	
24207	TROWEL ARM	4	
9059	NUT	8	
9066	SCREW	8	
9067	BOLT	4	
11903	BOLT	1	
21776	BEARING	1	
21757	SEAL	1	
50549	KEY	1	
31438	BEARING	1	
24258	BLADE, FINISH, 6"x10"	4	

PARTS LIST 8 – RIDE ON TROWELS

BXR830, SPRAY SYSTEM




Figure 8: Spray System

BXR830, SPRAY SYSTEM – PARTS LIST 8

Part #	Description	QTY	Remarks
8360589	HOSE, GAS	2	
24235	VALVE	1	
8360754	WATER PIPE	2	
8361071	JOINT	6	
24236	SOLENOID PILOT ACTUATED VALVE	1	
24237	WATER PUMP	1	
8361144	MOUNTING PLATE, WATER PUMP	1	

PARTS LIST 9 – RIDE ON TROWELS

BXR830, FOOT THROTTLE KIT




Figure 9: Foot Throttle Kit

BXR830, FOOT THROTTLE KIT – PARTS LIST 9

Part #	Description	QTY	Remarks
8360592	THROTTLE PEDAL	1	
8361425	THROTTLE PARTS	1	
8361426		1	
8361427		1	
8361428	THROTTLE CABLE SUPPORT	1	
24238	THROTTLE CABLE	1	
8810009411	RETURN SPRING	1	NOT SHOWN

PARTS LIST 10 – RIDE ON TROWELS

BXR830, FUEL TANK




Figure 10: Fuel Tank



BXR830, FUEL TANK – PARTS LIST 10

Item #	Part #	Description	QTY	Remarks
1	18157-4	WATER TANK BRACKET	1	
2	10192	GAS TANK HOLD DOWN BAR	1	
3	11043	WASHER, 1/4"	12	
4	11832	THREADED ROD, 1/4"-20 x 13"	4	
5	14596	HWHS 1/4"-20 x 1/2" LG THREAD CUTTING	2	
6	18150	GAS TANK	1	
7	50316	HHCS 1/4"-20 UNC x 1" LG	8	
8	11831	CARB CANISTER BRACKET	1	
9	18126	CARB CANISTER	1	
10	18124	CARB CANISTER BRACKET	2	
11	30141	LOCKNUT, 1/4"-20	16	
12	18157-3	SUPPORT	2	
13	18157-2	SUPPORT	1	
14	18157-1	GAS TANK BASE	1	

PARTS LIST 11 – RIDE ON TROWELS

BXR830, PROPANE TANK




Figure 11: Propane Tank



BXR830, PROPANE TANK – PARTS LIST 11

Item #	Part #	Description	QTY	Remarks
201	24249	PROPANE TANK MOUNT	1	
202	18157-2	SUPPORT	1	
203	18157-4	WATER TANK BRACKET	1	
204	18157-3	SUPPORT	2	
205	24263	PROPANE TANK	1	
206	50316	HHCS 1/4"-20 x 1" LG	7	
207	11043	WASHER, 1/4"	7	
208	30141	LOCKNUT, 1/4"-20	7	

PARTS LIST 12 – RIDE ON TROWELS

BXR830, STANDARD TRANSPORTER




Figure 12: Transporter



BXR830, STANDARD TRANSPORTER – PARTS LIST 12

Item #	Part #	Description	QTY	Remarks
1	22594	TRANSPORTER FRAME	1	
3	11200	3/8" WASHER	1	
4	12859	HHCS, 3/8-16 UNC X 2" LC	1	
5	10317	3/8-16 LOCKNUT, NYLON	1	
6	13198	WHEEL 16" DIA X 4" HUB	2	
7	12487	HITCH PIN LARGE 3-1/2" LG	2	
8	50265	COTTER PIN 1/8" DIA	2	
9	10509	HANDLE GRIP	2	
10	14717	PICKUP BAR	1	
11	14715	TRANSPORTER BRACKET	2	
12	14716	CHAIN LINK W/ 3/8" WASHER	1	

PARTS LIST 13 – RIDE ON TROWELS

BXR830, FRAME MOUNT TRANSPORTER




Figure 13: Transporter



BXR830, FRAME MOUNT TRANSPORTER – PARTS LIST 13

Item #	Part #	Description	QTY	Remarks
-	25120	TRANSPORTER, COMPLETE, INCLUDES BOTH SIDES	1	
-	25128	TRANSPORTER ASSEMBLY, SWIVEL CASTOR SIDE	1	
-	25129	TRANSPORTER ASSEMBLY, RIGID CASTOR SIDE	1	
1	25125	TRANSPORTER FRAME	1	
2	25124	RIGID, 6" CASTER WHEEL	2	
	25123	SWIVEL, 6" CASTER WHEEL	2	
3	14989	HHCS, M10-1.5x30MM	8	
4	41516	WASHER, M10	8	
5	11802	LOCKNUT, M10-1.5	8	



PAGE INTENTIONALLY LEFT BLANK



PAGE INTENTIONALLY LEFT BLANK

CONTRACTOR PROVEN EQUIPMENT SINCE 1946



170 Traders Blvd E
Mississauga, ON L4Z 1W7
Canada

4701 Allmond Avenue
Louisville, KY 40209
United States

200 Commerce Drive
Freehold, NJ 07728
United States

Honeyholes Lane
Dunholme, Lincoln LN2 3SU
United Kingdom



BartellGlobal.com